

TRANSPARENCY FILM FOR INKJET

Print on the textured rough side of the sheet only.
Ink will not stick to the smooth side.

Fan the transparencies before loading.

Place a few sheets of paper underneath them
or interleave for ease of handling.

The striped edge goes into the printer first.
Discard stripe after use.

Set your printer for transparency film or highest quality.

If you have any questions, please feel free to contact us.

ROCKLAND COLLOID
www.rockaloid.com